

INSTALLER MANUAL

Pellet Stove



©2026 CADEL srl | All rights reserved - Tutti i diritti riservati

VESTA

SUMMARY

1	MANUAL SIMBOLOGY.....	3
2	PACKAGING AND HANDLING.....	3
2.1	PACKAGING	3
2.2	REMOVING THE STOVE FROM THE PALLET	3
2.3	STOVE HANDLING.....	4
3	CHIMNEY FLUE	4
3.1	PREPARING THE SMOKE EXPULSION SYSTEM.....	4
3.2	CHIMNEY COMPONENTS	4
3.3	SMOKE DUCT (SMOKE FITTING).....	5
3.4	FLUE (CHIMNEY OR PIPED DUCT)	5
3.5	CHIMNEY POT.....	6
3.6	MAINTENANCE	7
4	COMBUSTION AIR.....	7
4.1	AIR INLET	7
4.2	COMBUSTIBLE AIR INLET FOR SEALED-CHAMBER INSTALLATION	8
5	EXAMPLES OF INSTALLATION (DIAMETERS AND LENGTHS TO BE SIZED)	9
6	INSTALLATION.....	10
6.1	INTRODUCTION	10
6.2	MINIMUM DISTANCES.....	11
6.3	INSULATING MATERIAL	12
6.4	OVERALL DIMENSIONS	12
6.5	STOVE DOOR REMOVAL/INSTALLATION	13
6.6	REMOVING/INSTALLING THE FRONT PANELS	14
6.7	REMOVAL/ASSEMBLY OF SIDE PANELS	14
6.8	HOT AIR DUCTING SYSTEM RIGHT.....	15
6.9	HOT AIR DUCTING SYSTEM LEFT	16
6.10	UPPER RIGHT HOT AIR DUCTING.....	17
6.11	INSTALLATION OF FINISHING CAPS.....	18
6.12	MOUNTING SERPENTINE STONE FRAME	19
6.13	REAR OR UPPER FUME EXHAUST	21
6.14	HOT AIR DUCTING PERFORMANCE.....	23
6.15	ELECTRIC CONNECTION	23
6.16	ROOM PROBE	24
6.17	CONNECTION TO THE EXTERNAL THERMOSTAT	24
7	SPECIAL MAINTENANCE	25
7.1	INTRODUCTION	25
7.2	FUME CHAMBER CLEANING	25
7.3	FUME CONDUIT CLEANING.....	26
7.4	FUME PASSAGE CLEANING.....	26
7.5	FUME FAN CLEANING	28
7.6	SELF-CLEANING BRAZIER CLEANING	28
8	IN CASE OF ANOMALY.....	29
8.1	PROBLEM SOLVING	29
9	TECHNICAL DATAS	32
9.1	REPAIR INFORMATION	32

1 MANUAL SIMBOLOGY

	USER
	PLEASE READ AND FOLLOW THE INSTRUCTIONS FOR USE CAREFULLY
	AUTHORISED TECHNICIAN (ONLY to interpret or the Stove-manufacturer or the Authorized Technician of Technical Assistance Service approved by the Stove-manufacturer)
	SPECIALIZED STOVE-REPAIRER
	CAUTION: READ CAREFULLY THE NOTE
	CAUTION: DANGER OR IRREVERSIBLE DAMAGE POSSIBILITY

- The icons with the stylized figures indicates whom the subject dealt in the paragraph is addressed to (between the User and/or the Authorized Technician and/or the Specialized Stove-repairer).
- **WARNING symbols indicates an important note.**
- The User manual is an integral and complementary part of the installer manual.

2 PACKAGING AND HANDLING

2.1 PACKAGING

- The packaging is made up of recyclable cardboard boxes according to RESY standards, recyclable expanded polystyrene inserts and wooden pallets.
- All packaging materials can be re-used for a similar use or eventually discharged as waste assimilable to the municipal solid ones, in accordance with current regulations.
- After having removed the packaging please assure you about the integrity of the product.

2.2 REMOVING THE STOVE FROM THE PALLET

Proceed as follows:




Fig. 1 - Bracket removal

- Remove the brackets which secure the feet of the stove (see **Fig. 1**). Then remove the stove from the pallet.

2.3 STOVE HANDLING

Both whether the stove is packed or not it is necessary to observe the following instructions for handling and transporting the stove from its sale point to its installation point and for any future movements:

- The stove must be handled with idoneous means paying attention to the existing safety regulations;
- do not turn the stove upside down and/or upset it on one side, but keep it in vertical position or as accorded with the constructor instructions;
- if the stove is made up of ceramic, stone, glass or any particularly fragile material components, all must be moved with the utmost care.

3 CHIMNEY FLUE

3.1 PREPARING THE SMOKE EXPULSION SYSTEM

The combustion product expulsion system is a particularly important element for the proper operation of the appliance and must be correctly sized according to EN 13384-1, EN 15287-1, EN 15287-2.

Its creation/adaptation/verification must always be carried out by a legally qualified operator and must comply with the regulations in force in the country where the appliance is installed.

The Manufacturer declines all liability for malfunctions caused by a badly sized and non-compliant smoke expulsion system.

3.2 CHIMNEY COMPONENTS




Fig. 2 - Chimney components

LEGEND	Fig. 2
1	Chimney pot
2	Fume outlet
3	Chimney flue
4	Thermal insulation
5	External wall
6	Chimney union
7	Fume pipe
8	Heat generator
9	Inspection door
10	T-union with inspection plug

3.3 SMOKE DUCT (SMOKE FITTING)

The smoke duct is the pipe that connects the appliance to the flue.

This smoke fitting must comply in particular with the following requirements:

- comply with product standard EN 1856-2, EN 15287-1, EN 15287-2;
- its cross-section must be of constant diameter **and no less** than that of the appliance outlet, from the firebox outlet up to the connection in the flue;
- the horizontal section must be as short as possible and extend no more than 4 metres;
- the horizontal sections must have a minimum upward slope of 3%;
- changes of direction must have an angle no greater than 90° and be easy to inspect
- the number of changes of direction, including that for entry into the flue, and exclusion of the T in the event of a side or rear outlet, must not exceed 3;
- it must be insulated if it passes outside the installation room
- it must not in any case cross rooms in which it is forbidden to install combustion appliances.
- the use of flexible metal and fibre cement or aluminium hoses is forbidden;

In any case, smoke ducts must be sealed against combustion products and any condensation. For this reason, it is recommended to use pipes with silicone gaskets or similar sealing devices that withstand the operating temperatures of the appliance (e.g. T200 P1) and that by removing the gaskets, are still T400 N1 G certified.

SYSTEM TYPE	Ø80 mm PIPE	Ø100 mm PIPE
Minimum vertical length	1,5 mt	2 mt
Maximum length (with 1 union)	6,5 mt	10 mt
Maximum length (with 3 unions)	4,5 mt	8 mt
Maximum number of unions	3	3
Level section (minimum inclination 3%)	4 mt	4 mt
Installation at a height above 1200 m a.s.l.	NO	Obligatory

3.4 FLUE (CHIMNEY OR PIPED DUCT)

When creating the flue, in particular comply with the following requirements:

- comply with the applicable product standard (EN 1856, EN 1857 EN 1457, EN 1806, EN 13063, EN 15287, EN 14989..)
- be made with suitable materials to ensure resistance to normal mechanical, chemical, thermal stresses and have adequate thermal insulation in order to limit the formation of condensate;
- have a predominantly vertical configuration and be free of choke points along its entire length;
- be correctly spaced by air gaps and isolated from combustible materials;
- the flue inside the house must still be insulated and can be inserted in an air shaft provided it complies with the regulations for piping;
- the smoke duct must be connected to the flue by means of a Tee fitting with an inspectable collection chamber for the collection of soot and any condensate.
- Where the sizing provides for wet operation, a suitable condensate collection and siphon discharge system must be set up.



We recommend checking the data plates of the flue for the safety distances that must be observed in the presence of combustible materials and, if necessary, the type of insulating material to be used.

It is forbidden to connect the stove to a collective or shared flue with other combustion appliances or with hood outlets.

It is forbidden to use the direct drain on the wall or towards indoor spaces and any other form of drain not provided for by the regulation in force in the country of installation.




Fig. 3 - Chimney Flues

LEGEND	Fig. 3
1	Chimney flue with insulated stainless-steel pipes
2	Chimney flue on the existing chimney
3	Inspection plug
4	Inspection door

- The chimney flue must be provided CE in accordance with EN 1443 regulation. Please find attached an example of label:




Fig. 4 - Example of label

3.5 CHIMNEY POT

The chimney pot, meaning the end part of the flue, must meet the following characteristics:

- the smoke outlet section must be at least double the internal section of the chimney;
- prevent the penetration of rain or snow;
- ensure the outlet of smoke even in the event of wind (windproof chimney pot);
- the height of outflow must be beyond the reflux area (**) (refer to national regulations to identify the reflux area);
- always be built at a distance from antennas or dishes, and never be used as a support.

(**) unless there are specific national derogations (clearly specified in the corresponding instruction manual in English) which under appropriate conditions allow it; in this case, strictly follow the product/installation requirements of the relative regulations/technical specifications/legislation in force in that country.




Fig. 5 - Anti-wind chimney pots




Fig. 6 - Reflux area

3.6 MAINTENANCE

- The fumes extraction pipes (fumes conduit + chimney flue + chimney pot) must always be cleaned, scrubbed and checked by an expert stove-repairer, in compliance with current regulations, with the instructions of the stove-manufacturer and the directives of your insurance company.
- In case of doubts, please follow the most restrictive regulations.
- Have your chimney flue and chimney pot checked and cleaned by an expert chimney sweep at least once a week. The chimney sweep has to release a written declaration about the security of the system.
- Not cleaning compromise safety.

4 COMBUSTION AIR

4.1 AIR INLET

It is mandatory to provide an adequate external air inlet that supplies the combustion air required for the product to work properly. The flow of air between the outside and the installation room can take place with a free air inlet or by channelling the air directly to the outside (***)

The free air inlet must be:

- be made at floor level and in any case not higher than the height of the appliance;
- always be protected with an outer grille and in such a way that it cannot be obstructed by any object;
- have a minimum total free area of 80 cm² (net of the grille);

The presence of other suction devices (e.g.: vmc, electric fan for stale air extraction, kitchen hood, other stoves, etc.), in the same room, or in communicating rooms of the same housing unit, could cause negative pressure in the room. In this case, with the exception of sealed installations, one must verify that, with all the equipment on, no more than 4 Pa of negative pressure is created inside the installation room with respect to the outside. If necessary, increase the air inlet section.

It is possible to duct the air required for combustion to the outside by connecting the external air inlet directly with the combustion air inlet which is usually found on the back of the appliance.

The external ducted air vents must be:

- made close to the floor and anyway not higher than the appliance
- protected by a grille that guarantees a clear surface equal to 50 cm² and made so that it cannot be obstructed by any object
- The air vent can be made directly on a wall of the installation room communicating with the outside, or indirectly in adjacent rooms that permanently communicate with the installation room, according to that set forth by standards in force.

The minimum size of the installation room must be at least 80 m³.

The channelling duct must have a maximum length of 1 m (including the 2 90° bends)

(***) In the event the combustion air is ducted on unsealed products, still verify that no more than 4 Pa of negative pressure is created inside the installation room with respect to the outside, otherwise provide for an additional air intake in the room.

Below 15 kW:

Air duct diameter	Maximum length (smooth duct)	Maximum length (corrugated duct)
50 mm	2 m	1 m
60 mm	3 m	2 m
80 mm	7 m	4 m
100 mm	12 m	9 m

Above 15 kW:

Air duct diameter	Maximum length (smooth duct)	Maximum length (corrugated duct)
50 mm	-	-
60 mm	1 m	-
80 mm	3 m	1 m
100 mm	7 m	4 m




Fig. 7 - Direct air inflow




Fig. 8 - Air inlet for sealed-chamber installation

LEGEND	Fig. 7 Fig. 8
1	Room to ventilate
2	External air inlet
4	Shield grid
5	Curve inlet to turn downwards
6	Terminal (alternative)

4.2 COMBUSTIBLE AIR INLET FOR SEALED-CHAMBER INSTALLATION

How to connect to the stove in the sealed chamber with concentric system:



Fig. 9 - Phase1



Fig. 10 -

- Connect the air intake pipe to the combustion air pipe of the stove and tighten everything with a clamp (see Fig. 9). If the combustion air pipe is Ø 5cm, it must be brought to Ø 6cm, using a fitting (code 5023003). (see Fig. 10). The minimum size of the room must be 32 m³.

5 EXAMPLES OF INSTALLATION (DIAMETERS AND LENGTHS TO BE SIZED)




Fig. 11 - Chimney flue

1. Flue installation with hole for the passage of the pipe increased by: minimum 100mm around the pipe if next to non-flammable parts such as cement, brick, etc.; or minimum 300mm around the pipe (or as required by plate data) if next to flammable parts such as wood etc. In both cases, install suitable insulation between the flue and the ceiling. Always check and comply with the plate data of the flue, specifically the minimum safety distances from combustible materials. The previous rules also apply for holes made in walls.

2. Old flue, pipe with the inclusion of an external access door for chimney cleaning.

3. External flue made of insulated stainless-steel pipes, i.e. with double walls: all securely mounted on the wall. With windproof chimneypot.

4. Ducting system using Tee fittings that allow easy access for cleaning without having to remove the pipes.

LEGEND	Fig. 11
U	Insulation
V	Possible diameter increase
I	Inspection cap
S	Inspection access panel
P	Air inlet
T	T-fitting with inspection cap
A	Distance from flammable material (smoke duct plate)
B	Maximum 4 m
C	Minimum 3° slope
D	Distance from flammable material (appliance plate)
E	Reflux area
F	Air ducting



The instructions in this chapter refer explicitly to the Italian installation regulation UNI 10683. In any case, always observe the regulations in force in the country of installation.

6 INSTALLATION

6.1 INTRODUCTION

The heating system (generator + combustion air supply + combustion product expulsion system + any hydraulic/aeraulic system) must be installed in compliance with the laws and regulations in force (*), and carried out by a qualified technician, who must issue a declaration of conformity of the system to the system manager and shall undertake full responsibility for final installation and consequent good operation of the product.

The manufacturer declines all responsibility in the event of installations that do not comply with the laws and regulations in force and inappropriate use of the appliance.

In particular one must ensure that:

- the environment is suitable for installing the appliance (floor load-bearing capacity, presence or possibility of creating an adequate electrical/hydraulic/aeraulic system when required, volume compatible with the appliance characteristics, etc.);
- the appliance is connected to a smoke expulsion system correctly sized according to EN 13384-1, which is resistant to soot fire and which complies with the distances prescribed by the combustible materials indicated on the plate data;
- there is a suitable combustion air flow to the appliance;
- other combustion appliances or extraction devices installed do not cause a negative pressure of more than 4 Pa in the room where the product is installed compared to the outside (only sealed appliances are allowed a maximum of 15 Pa of negative pressure in the room).

(*) The national reference standard for the installation of domestic appliances is UNI 10683 (IT) - DTU NF 24.1 (FR) - DIN 18896 (DE) - NBN B 61-002 (BE) - Real Decreto 1027/2007 (ES) - Paesi Bassi (NL) Bouwbesluit - Danmark (DK) BEK n° 541 del 27/04/2020.

In particular, it is recommended to strictly observe the safety distances from combustible materials to avoid serious harm to people and to the integrity of the home.

Installation of the appliance must ensure easy access to service the appliance itself, the smoke channels and the flue. Always maintain adequate distance and protection in order to prevent the product from coming into contact with water.

It is forbidden to install the stove in rooms with a fire hazard.

With the exception of sealed installations, it is also forbidden for liquid fuel appliances with continuous or intermittent operation that draw the combustion air from the room they are installed in or B-type gas heating appliances, with or without the production of domestic hot water, to coexist in the same room or in interconnecting rooms.



Sealed installation means that the product is certified as sealed and its installation (ducting of the combustion air and connection to the chimney) is airtight with respect to the installation environment.

A sealed installation does not consume the room's oxygen because it draws all the air from the outer environment (if suitably ducted) and makes it possible to install the product in all houses that require a high degree of insulation such as "passive" or "high energy efficiency" houses. Thanks to this technology there is no risk of smoke emissions in the room and no air inlets - hence not even the relevant ventilation grilles - are required in the installation premises.

Consequently, there will be more draughts of cold air in the room, thus making it more comfortable and increasing the overall efficiency of the system. The sealed stove in a sealed installation is compatible with the presence of forced ventilation or premises that might have negative pressure with respect to the outside.

6.2 MINIMUM DISTANCES

Observe the distances from flammable objects (sofas, furniture, wood panelling, etc..) as specified in the following diagram.

If objects considered to be particularly sensitive to heat are present, such as furniture, curtains or sofas, as a precaution, increase the stove clearances substantially to avoid possible deterioration due to the effect of heat.




Fig. 12 - Safety distances from combustible material.

.LEGENDA	Fig. 12
dR (rear distance)	5 mm
dS (side distance)	300 mm
dB (lower distance)	0 mm
dC (upper distance)	750 mm
dP (front radiation)	900 mm
dF (floor radiation)	0 mm
dL (side radiation)	0 mm
1	FLOOR
2	FRONT FLAMMABLE MATERIAL
3	AREA SUBJECT TO RADIATION
4	FLOOR GUARD
5	RADIATED SURFACE TO BE PROTECTED
6	REAR/SIDE/UPPER FLAMMABLE SURFACE

If the floor is made of combustible material, use a protection made of non-combustible material (steel, glass...) that also protects the front from any falling combusted material during cleaning operations.



Always fit a floor guard if the floor is made of flammable material.

Install the stove also detached from any non-combustible walls/surfaces, observing a minimum clearance of **5mm** (back) and **300mm** (side) to allow effective aeration of the appliance and a good distribution of heat in the room.

In any case, ensure adequate distance to facilitate access during cleaning and extraordinary maintenance. If this is not possible, it must still be possible to distance the product from adjacent walls/elements.

This operation **(1*)** must be performed by a technician qualified to disconnect the combustion product expulsion ducts and their

subsequent restoration.

For generators connected to the hydraulic system, a connection must be provided between the system itself and the product so that, during extraordinary maintenance, carried out by a qualified technician, it is possible to move the generator 1 by at least 50 cm from adjacent walls without emptying the system (e.g. by using a double shut-off gate or suitable flexible connection).

(1*) The national reference standard for the installation of domestic appliances is UNI 10683 (IT) - DTU NF 24.1 (FR) - DIN 18896 (DE) - NBN B 61-002 (BE) - Real Decreto 1027/2007 (ES) Paesi Bassi (NL) Bouwbesluit - Danmark (DK) BEK n° 541 del 27/04/2020.

6.3 INSULATING MATERIAL

The probable insulating material to use must have the following technical features:

DESCRIPTION		VALUE
Material thickness		40 mm
Screening temperature		1000 °C
Density		245 Kg/m ³
Shrinkage at referring temperature (12h)		1,3 % /1000 °C
Cold crushing strenght		1,4 MPa
Bending strenght		0,5 MPa
Thermal expansion coefficient		5,4x10 ⁻⁶ m/mK
Specific heat		1,03 Kj/kgK
Thermal conductivity at medium temperature	200 °C	0,07 W/mK
	400 °C	0,10 W/mK
	600 °C	0,14 W/mK
	800 °C	0,17 W/mK

6.4 OVERALL DIMENSIONS




Fig. 13 - VESTA PLUS 11

LEGEND	Fig. 13
A	Exhaust fumes Øcm 8
B	Hole combustion air inlet Øcm 6
C	Ducting outlet Øcm 8




Fig. 14 - VESTA PLUS 11 UP-TWIN

LEGEND	Fig. 14
A	Exhaust fumes Øcm 8
B	Hole combustion air inlet Øcm 6
C	Ducting outlet Øcm 8

6.5 STOVE DOOR REMOVAL/INSTALLATION

DOOR REMOVAL

For some operations (e.g.: side panel assembly and cleaning) you must remove the stove door.

To remove the door:

- Open the door.
- Use a screwdriver to rotate the lever in the direction of the arrow (vedi **Fig. 15**).
- Lift the door to allow the door pivots to slide out of the structure bracket (see **Fig. 16**).
- Keep the door in a safe place until next use.



Fig. 15 - Remove screws



Fig. 16 - Door removal

DOOR ASSEMBLY

To assemble the door you must centre the pivots fixed to the door, on the structure bracket. After having mounted the door with the screwdriver, lift the lever so that the door is locked.

6.6 REMOVING/INSTALLING THE FRONT PANELS

To remove the front panels, proceed as follows:

- Undo the two lower screws using a 7 mm wrench (see **Fig. 17**).
- Unhook the panel (see **Fig. 18**).




Fig. 17 - .



Fig. 18 - .

6.7 REMOVAL/ASSEMBLY OF SIDE PANELS

To disassemble the side panels, proceed as follows:

- Unscrew the 4 screws on the side panel (see **Fig. 19**).
- Release the panel (see **Fig. 20**).




Fig. 19 -.




Fig. 20 -.

6.8 HOT AIR DUCTING SYSTEM RIGHT

The stove is equipped with two front hot air outlets:

- Remove the front panels (see dedicated chapter).
- Unscrew the two box support screws **Fig. 21**.
- Remove the box **Fig. 22**.




Fig. 21 -.



Fig. 22 -.




Fig. 23 -.




Fig. 24 -.

Insert the 80 mm diameter flexible pipe **Fig. 23**.
Choose whether to use a side or rear outlet **Fig. 24**.

6.9 HOT AIR DUCTING SYSTEM LEFT

The stove is equipped with two front hot air outlets:

- Remove the front panels (see dedicated chapter).
- Unscrew the two box support screws **Fig. 25**.
- Remove the box **Fig. 26**.




Fig. 25 -.




Fig. 26 -.




Fig. 27 -.

Insert the 80 mm diameter flexible pipe **Fig. 27**.
Choose whether to use a side or rear outlet.

6.10 UPPER RIGHT HOT AIR DUCTING

After removing the right-hand casing (see dedicated chapter):

- Unscrew the three fan fastening screws, rotate it 180°, and screw it back in **Fig. 28**.
- Insert the 80mm diameter flexible hose **Fig. 29**.



Fig. 28 -.




Fig. 29 -.

6.11 INSTALLATION OF FINISHING CAPS

- After installing the ducting, proceed with the installation of the two finishing caps.
- Two caps are located at the base of the stove; using a flat-head screwdriver, remove the two elements as shown in **Fig. 30** **Fig.31**.




Fig. 30 -.




Fig. 31 -.

Insert the right cap and tighten the two screws as shown in **Fig. 32** **Fig. 33**.




Fig. 32 -.




Fig. 33 -.

Insert the left cap and tighten the two screws as shown in **Fig. 34** **Fig. 35**.




Fig. 34 - .




Fig. 35 - .

6.12 MOUNTING SERPENTINE STONE FRAME

To assemble the frame, proceed as follows:

- Tighten the screws to the stone (see **Fig. 36**), the screw head must protrude about 1.5 mm (see **Fig. 37**).



Fig. 36 - Tighten the screws



Fig. 37 - The screw must protrude

Starting with the lower stone, align the heads of the 4 screws with the corresponding slots in the support until the entire stone is fully engaged **Fig. 38 Fig. 39**.




Fig. 38 -




Fig. 39 -

Proceed with the side stones, always aligning the 4 screws with their respective slots and sliding the stone downward until it comes into contact with the lower stone **Fig. 40 Fig. 41**. During this operation, carefully ensure that all 4 screws are perfectly seated in their respective positions.



Fig. 40 -



Fig. 41 -

Finally, install the upper serpentine stone following the same procedure **Fig. 42**.



Fig. 42 - .

To perform maintenance on the lower section of the flue gas passage (see the dedicated chapter), it is possible to remove ONLY the lower serpentine stone by disengaging it towards the right **Fig. 43 Fig. 44**. This provides access to the flue gas passage. To reinstall it, refer to the beginning of this chapter.




Fig. 43 - .



Fig. 44 - .

6.13 REAR OR UPPER FUME EXHAUST

The connection of the fume exhaust can be at the back or on top.

REAR EXHAUST

- Position the pipe as shown in [Fig. 45




Fig. 45 -.

UPPER EXHAUST

- Loosen the clamp **Fig. 46**, rotate the connector, and tighten the clamp again (see **Fig. 47**).




Fig. 46 -.



Fig. 47 -.

6.14 HOT AIR DUCTING PERFORMANCE



Fig. 48 - Ducting system example

- A stove with no ducting has a variable air flow rate from a minimum of 59 m³/h to a maximum of 100 m³/h, and an air temperature which varies from a minimum of 80°C to a maximum of 110°C; these data are valid for each of the 2 outputs.
- In the case of ducting, it is recommended not to exceed 8 metres of pipe and 3 x 90° bends, otherwise the hot air loses its effectiveness.
- Use pipes with an 80 mm diameter with smooth internal walls.
- If the pipes pass through cold walls, insulate the pipe with insulating material.
- Place a protective grille with large mesh and a total minimum net surface area of 24 cm² over the outlet.
- There can be a variable air flow rate from a minimum of 35 m³/h to a maximum of 80 m³/h and an air temperature which varies from a minimum of 40°C to a maximum of 90°C after the 8 metres of pipe. (These values were recorded in the testing laboratory; there may be differences in flow and temperature in the installation room).
- If you wish to increase the air flow, install a small wall-mounted fan on the outlet with a flow rate of more than 80 m³/h; this should be performed by an authorised technician.
- With the factory parameters, 40% of the heat produced by the stove is conveyed into the room where it is installed and the remaining 30% comes out from the ducting on the right and 30% from the left one.
- To get the best performance you need to balance the power with the air flow. This operation must be performed with the assistance of an authorised technician.
- The ductable fans cannot be deactivated, but they can be operated at a power value between 1 and 5 or in automatic mode.

6.15 ELECTRIC CONNECTION



Warning: the appliance must be installed by an authorized technician!

- The electric connection occurs through a cable with plug put in an electric socket which is able to support charge and tension specific of every model, as described on the CE Plate.
- The plug must be easily accessible when the appliance is installed.
- Please further assure you that your network is endowed with an efficient earth connection: if it does not exist or if it is not efficient, please endow you with one in compliance with the law.
- Connect the supply cable first on the back of the stove (see **Fig. 49** and **Fig. 50**) and then at a wall electric socket.



Fig. 49 - Electric socket with master switch



Fig. 50 - Plug connected

- Do not use extension cables.
- If the feeder cable is damaged, it must be replaced by an authorized technician.
- When the stove is not going to be used for a long period of time, it is advisable to remove the plug from the socket on the wall.
- An electrical connection to a UPS/ACCUMULATOR/ STABILISER must guarantee a voltage of at least 210V without power surges. Considering the variety of UPS on the market regarding size and construction qualities, we cannot guarantee operation once the stove is connected to these devices.
- Voltage - Power frequency: 230V - 50Hz

6.16 ROOM PROBE

The stove is equipped with a room sensor, locked internally with a cable gland. If you wish to move the room temperature detection point, loosen the nut and remove the probe **Fig. 51**. If this is not sufficient, the sides must be opened and the available part of the internal cable pulled out **Fig. 52**; the probe will stretch 20 to 40 cm depending on the stove model.



Fig. 51 - Unscrew the nut



Fig. 52 - Room probe 2

6.17 CONNECTION TO THE EXTERNAL THERMOSTAT



Fig. 53 - Graphic display

The stove works through a thermostat probe placed in its inner. If you desire, the stove can be connected to an external room thermostat. This operation must be executed by an authorized technician.

Connect the wires from the external thermostat to the "Term opt" terminal on the stove board. Activate the external thermostat (default setting OFF) as indicated below:

- Press the **"menu"** button.
- Scroll with the arrows to **"Settings"**.
- Select by pressing **"menu"**.
- Scroll with the arrows again to **"Ext.Thermostat"**.
- Select by pressing **"menu"**.

- Press the - + buttons.
- To activate the external thermostat select "on".
- Press the "menu" button to confirm.

7 SPECIAL MAINTENANCE

7.1 INTRODUCTION

For a long working life of the stove, have a periodic cleaning of the stove as described in the following paragraphs.

- Fume outlet pipes (fume conduit + chimney flue + chimney pot) must always be cleaned, scrubbed and checked by an authorized technician in compliance with local regulations, with the instructions of the manufacturer and those of your insurance company.
- If there are no local regulations and no instruction from your insurance company, it is necessary to have your fume pipe, chimney flue and chimney pot cleaned at least once a year.
- It is also necessary to have the combustion chamber, motors and fans cleaned and to have the gaskets and the electrical elements checked at least once a year.



All these operations must be planned in time with your Authorized Technical Assistance Service.

- After a long ineffective time, before turning on the stove check if there are obstructions in the fume exhaust.
- If the stove had been using continuously and intensely, the whole system (chimney included), must be cleaned and checked more frequently.
- In case of replacement of damaged pieces please ask for the original spare part at the Authorized Retailer.

7.2 FUME CHAMBER CLEANING

Every end-of-season (or every 2000 hours of operation) it is necessary to clean the fume chamber.

- Open the door and release the panel below the door (see dedicated chapter).
- Remove the burning pot (see [XREF-2:46573]) from its seat and empty all ash.
- Clean and vacuum the burning pot compartment of any ash accumulated inside (see **Fig. 55**).
- Remove the inspection cap (see **Fig. 68**).



Fig. 54 - Remove the burning pot



Fig. 55 - Vacuum out the ash



Fig. 56 - Remove the cap

- Clean with a pipe cleaner and suction any ash accumulated inside (see **Fig. 57** and **Fig. 67**).
- After cleaning, repeat the operation in reverse making sure the gasket is intact and efficient: if necessary, have it replaced by an authorised technician.



Fig. 57 - Clean with pipe cleaner



Fig. 58 - Vacuum out the ash

7.3 FUME CONDUIT CLEANING

The exhaust system must be cleaned every 2/3 months.



Fig. 59 - Fume conduit cleaning

- Remove the inspection lid of the T-union (see **Fig. 59**).
- Extract the ash which has accumulated in the inner.
- After cleaning repeat the operation in reverse order, checking the condition and efficiency of the gasket, and if necessary replace it.



It is important to sealed the cap othrwise noxious fumes will propagate among the room.

7.4 FUME PASSAGE CLEANING

Every end-of-season (or every 2000 hours of operation) it is necessary to clean the fume passages.

- Remove the lower panel **Fig. 60**.
- Unscrew the hex-head screws securing the cast iron firebox panels on both sides (see **Fig. 61**).
- Push the firebox top panel upwards (see **Fig. 62**), tilt the component and remove it (see **Fig. 63**).
-



Fig. 60 -



Fig. 61 -




Fig. 62 -



Fig. 63 -



Fig. 64 - Remove the rear firebox panel



Fig. 65 - Remove the side firebox panels

- Remove the rear firebox panel (see **Fig. 64**).
- Then remove the side firebox panels (see **Fig. 65**).
- Clean with a brush and vacuum any ash accumulated inside (see **Fig. 66**).
- Part of the ash will fall into the compartment below the firebox (see **Fig. 67**). For cleaning, refer to the section "Fire chamber cleaning".



Fig. 66 - Clean with pipe cleaner



Fig. 67 - Vacuum out the ash

7.5 FUME FAN CLEANING

Clean every the year the fume fan from ash or dust which can cause a blade unbalance and a greater noise.

- Open the door and release the panel under the door (see dedicated chapter).
- Remove the inspection cap (see **Fig. 68**).
- Unscrew the 2 screws of the smoke deflector inside (see **Fig. 69**) and remove it (see **Fig. 70**).



Fig. 68 - Remove the cap



Fig. 69 - Unscrew the screws




Fig. 70 - Remove the fume diverter

- Vacuum the blades of the fume extraction fan (see **Fig. 71**).
- After cleaning, repeat the operation in reverse making sure the gasket is intact and efficient: if necessary, have it replaced by an authorised technician.




Fig. 71 - Vacuum out the ash

7.6 SELF-CLEANING BRAZIER CLEANING

- Open the door.



Fig. 72 - Burning pot extraction




Fig. 73 - Burning pot cleaning

- Extract the burning pot (see **Fig. 72**) from its seat.

- If necessary clean with a pointed object the holes obstructed by encrustations (see **Fig. 73**).



Fig. 74 - Burning pot box cleaning



Fig. 75 - Cleaning with a brush

- Clean and drain away the burning pot box and ash tray box from ash which has accumulated in its inner (see **Fig. 74**).
- Clean also the hole for pellet drop with a brush (see **Fig. 75**).
- The ash remains must be poured in a metal container with a sealed lid and this container must never get in touch with combustible materials (for example put on a wooden floor), as the inner ash keeps the embers firing for a long time.
- Only when the embers are off the ash could be poured in the organic waste.
- Pay attention if the flame becomes red colored, if it is weak or if black smoke creates in the inner: in this case the burning pot is encrusted and needs to be cleaned. If it is broken, it must be replaced.



CAUTION: cleaning must be carried out with the stove switched off, there may be moving gears.

8 IN CASE OF ANOMALY

8.1 PROBLEM SOLVING



Before of every Authorized Technician intervention, the same Technician has the duty to check if the parameters of the mother board correspond to those of the table you own.



In case of doubts regarding the use of the stove, please contact ALWAYS the Authorized Technician on order to avoid irreparable damages!

PROBLEM	CAUSE	SOLUTION	INTERVENTION
The control display does not switch on	The stove is without power supply	Check if the plug is connected.	
	Burned protection fuse in the electric socket	Replace the protection fuses in the electric socket (3.15A-250V).	
	Faulty control display	Replace the control display.	
	Faulty flat cable	Replace the flat cable.	
	Faulty electronic board	Replace the mother board.	

PROBLEM	CAUSE	SOLUTION	INTERVENTION
Pellets do not reach the combustion chamber	Empty hopper	Full the hopper.	
	Open fire door or open pellet door	Close fire door and pellet door and check that there are no pellet grains at the gasket level.	
	Clogged stove	Fume chamber cleaning	
	Auger blocked by a foreign object (for example nails)	Clean the auger.	
	The auger geared motor is out of order	Replace the geared motor.	
	Check if on the display there is an "ACTIVE ALARM"	Have the stove checked.	
The fire extinguish and the stove stops	Empty hopper	Full the hopper.	
	Auger blocked by a foreign object (for example nails)	Clean the auger.	
	Bad quality pellets	Try other types of pellets.	
	Pellet drop value too low "phase 1"	Adjust the pellet loading.	
	Check if on the display there is an "ACTIVE ALARM"	Have the stove checked.	
	The door does not close perfectly or the gaskets are worn	Check the door seal and replace the gaskets.	
	Ignition step is not completed	Empty the brazier and repeat ignition.	
	Clogged exhaust	The exhaust chimney is partially or totally obstructed. Call a skilled chimney technician to check from the stove exhaust to the chimneypot. Clean immediately.	

PROBLEM	CAUSE	SOLUTION	INTERVENTION
Flames are weak and orange coloured, pellets do not burn properly and the glass blackens	Not sufficient combustion air	Check as following: probable obstructions of the combustible air inlet from the back or from the bottom of the stove; burning pot obstructed holes with too ash remains. Have the fan blades and auger cleaned. (see SMOKE RPM VARIATION User Manual)	
	Obstructed exhaust	The exhaust chimney is partially or totally obstructed. Contact an expert stove-repairer who checks the stove from the exhaust up to the chimney pot. Provide immediately for stove cleaning.	
	Obstructed stove	Provide immediately at the inner cleaning of the stove.	
	The fume fan is out of order	The pellets can burn also thanks to chimney flue depression without the aid of the fume fan. Have the fume fan immediately replaced. It can be noxious to health to let the stove running without fume fan.	
The exchanger fan continues to turn even though the stove has just cooled	Faulty fume temperature probe	Replace the fume probe.	
	Faulty mother board	Replace the mother board.	
Ash remains along the stove	Faulty or out of order door gaskets	Replace the gaskets.	
	Not sealed fume pipes	Contact an expert stove-repairer who will immediately provide for sealing the junctions with high-temperature silicone and/or for replacing pipes with those in compliance to current regulations. A not sealed fume channelisation can be noxious to health.	
The stove is at its highest power but does not heat up.	Ambient temperature reached.	The stove is at its minimum value. Increase the desired ambient temperature.	
Stove running and display showing "Smoke Overtemperature"	Reached fume outlet limit temperature	The stove runs at minimum. NO PROBLEM!	
The stove's smoke duct produces condensation	Low smoke temperature	Check that the flue is not clogged.	
		Increase stove power to minimum (pellet drop and fan revs).	
		Install condensation collection cup.	
Stove running and display showing "SERVICE"	Routine maintenance alert (it does not block the system)	When this flashing message appears upon start-up, it means that the preset operating hours have elapsed before maintenance. Contact the service centre.	

9 TECHNICAL DATAS

9.1 REPAIR INFORMATION

Now we give some instructions for the Authorized Technician to take into consideration to have access to stove mechanical components.

- For fuse replacement in the electric socket which stands on the back of the stove, extract the fuses to change with the aid of a screwdriver for opening the shutter (see **Fig. 76**).




Fig. 76 - Shutter with fuses to remove

Proceed as follows:

- Remove the frame (see the dedicated chapters).
- After these operations you can have access at the following components: geared motor, ignition plug, ambient fan, fume fan, ambient probe, fume probe, thermostat, electronic board, pressostat.
- For cleaning or replacement of the auger it is necessary to unscrew the three bolts of the geared motor and to extract it, unscrew the two screws lying under the geared motor (vedi **Fig. 77**), of the auger, remove the hand rejector inside the hopper and then unscrew the inner bolt of the auger. (vedi **Fig. 78**). To assembly proceed at the contrary.




Fig. 77 - Remove the screws



Fig. 78 - Remove the screw

89026029B

Rev. 00- 2026

CADEL srl
31025 S. Lucia di Piave - TV
Via Martiri della Libertà, 74 - Italy

www.cadelsrl.com
www.free-point.it